


















G30 / G30S







PL: INSTRUKCJA MONTAŻU
EN: ASSEMBLY MANUAL
CZ: PŘÍRUČKA PRO MONTÁŽ
SK: PRÍRUČKA PRE MONTÁŽ
DE: MONTAGEANLEITUNG
SR: UPUTSTVO ZA INSTALACIJU

G30 / G30S





A x8  Ø8x35mm	B x8 	C x8  Ø15x12mm	E x4 
G x20 	M x1 	N1 x2 	N2 x2 
W2 x4  Ø3,5x16	W8 x4  Ø4x30mm	Y x8  Ø18 mm	
Zc x2  Zc-1  Zc-2			



1





2



3




4





A=B


5







6





7



8

















G40 / G40S







PL: INSTRUKCJA MONTAŻU
EN: ASSEMBLY MANUAL
CZ: PŘÍRUČKA PRO MONTÁŽ
SK: PRÍRUČKA PRE MONTÁŽ
DE: MONTAGEANLEITUNG
SR: UPUTSTVO ZA INSTALACIJU

G40 / G40S





A x8  Ø8x35mm	B x8 	C x8  Ø15x12mm	E x4 
G x20 	M x1 	N1 x2 	N2 x2 
W2 x4  Ø3,5x16	W8 x4  Ø4x30mm	Y x8  Ø18 mm	
Zc x2  Zc-1  Zc-2			



1





2



3




4





A=B


5



6



7



8

